Trolley Error Code			
	Code Explanation	Resolution	Remark
ZE07	Cable loose of left lifting frame	1. Open the cover of red part in Pic1 2. Plug in and out the cables of left lifting part as Pic2 (one yellow cable and one black) 3. do RESET	 Pic1
E08	Cable loose of right lifting frame	1. Open the cover of red part in Pic1 2. Plug in and out the cables of right lifting part as Pic2 (one yellow cable and one black) 3. do RESET	 Pic2
H01	Overheat and overload protect	Do RESET	Occurs when working continuously for 4 minutes, will work as usual after 16 minutes
			Occurs when load over 100KG

How to do **RESET**

connect the power, and press the down button for 5 seconds, the above code flickers. Press and hold the down button again, the lifting frame will lift up and the screen shows height, reset completes.